



micro DV Camcorder / WebCam

model DVR-007

User Manual

Thank you for purchasing the micro DV Camcorder / Web Cam DVR-007. Its ultra small size, light weight and excellent audio and video resolution lends itself to many applications..



I Product Features

- Small light design 0.7 oz. (21 g) with plastic clip can be worn in a shirt pocket or attached to hat, belt, RC Cars, Boats, Airplanes, Helicopters, model rockets, Robots, your pet and anything you can think of.
- Amazing DVD quality 720X480 at 30 fps video with audio from built in sensitive microphone and 1280*1024 still image resolution.
- USB Plug and Play – Looks and works like a thumb Drive!
- Can be used as a Webcam with included Windows Drivers, works with Skype, MSN, Yahoo and AIM and many surveillance programs.
- 2 hour operation from internal Lithium battery with built-in USB charger
- Tiny 74 x 21 x 13mm (2.8 x 0.8 x 0.5inches)
- Supports AVI video format.
- Amazing low light capabilities for a camera this small.
- Supports USB1.1 and USB2.0.
- Support up to **8GB Trans-flash SD card**.(maximum)

II Operation

1. Charging

The camera has a built-in lithium rechargeable battery. Please completely charge the battery before you begin using your new camera. Charging is as follows:

- 1.) Connect the supplied USB cable to the camera.
- 2.) Connect the other end of cable to a USB connector on you computer.

When you plug it in, the red indicator light will flash twice and remain on, the green light flashing indicates a charge is in progress. The green light will stop flashing and remain on when the when the battery is fully charged.

Notice: If the battery has been severely discharged the unit will enter into a battery protection mode, and will not power up. Leave it on charge for about two hours to insure a full charge.

2. Shooting Video – Video Mode

- 1) Insure that the ‘Video/Photo’ button is in the “Video” position. Insure the “ON/OFF” power button to “ON”



- 2) Momentarily pres the “Record/Stop ” button to wake up the camera. The green light comes on to signal it is ready and flashes the red light once. When you are ready to shoot video, momentarily press the “Record/Stop” button again, At this time, video recording begins and the red indicator light starts to flash while recording. The resolution for video file is fixed at 720*480, at 30fps (frames per second).



3) To stop recording, momentarily press the “Record/Stop” button again, The red light will flash rapidly and go off, your video is stopped and saved automatically. After saving, the green indicator light will remain on for 60 seconds. If you want to continue shooting video, momentarily press the “Record/Stop” button once more.

Note:

- a. Please make sure that a Trans-flash (Micro SD) card has been inserted into the side slot, if not, the green light will repeatedly flash and the camera will power off automatically after 60 seconds.
- b. The maximum capacity of Trans-flash SD card is 8GB.
- c. Saving a file takes a few seconds after you stop recording, please wait until the red light goes out before initiating a new video.
- d. For best color and clarity insure there is ample even lighting and maintain a distance of at least 20 inches – (50cm). This will insure that the video will be in focus and have natural colors.
- e. **IMPORTANT:** Leave the power button switched on to maintain the correct day and time. (See Setting Time below.)

3. Shooting Still Images – Photo Mode

Insure that the “ON/OFF” button is set to “ON”, and move the ‘Video/Photo’ button to the “Photo” position. Momentarily pres the “Record/Stop ” button to wake up the camera. The green light comes on to signal it is ready and flashes the red light once. Momentarily press the “Record/Stop” button again to shoot the photo. The red light will flash a few times and shut off. Please wait until the red light stops flashing before pressing again. Photo images are saved as a jpg file in a resolution of 1280*1024.

4. Setting the Date and Time

Included on the SD card or available online at <http://tmenet.com/support/downloads> are the support files for setting up the date and time in the internal clock/calendar of your camera. You will need to perform the following steps to set the time:

1. Locate the text file text called TAG.TXT and copy it to the root directory of the SD card.
2. Open the file TAG.TXT with notepad or any simple text editor, modify the date and time in the file while retaining the exact format shown below:

[date] need space with newline/carriage return

2010/03/05 need space with newline/carriage return in format yyyy/mm/dd

12: 00: 00 enter hours, minutes, seconds with newline/carriage return hh: mm; ss

Close the file by exiting and put the SD card in the camera or if card was already in the camera and editing was done via USB, simply unplug the USB cable and power on the camera. This action will force it to check and analyze the TAG.TXT file and then set system time to the time you entered in the file. The text file TAG.TXT will be deleted automatically.

5. Power off

For long term storage we recommend you power your unit off. **Please note this will reset the date and time.** Push the “ON/OFF” button to “OFF”. This immediately turns off the camera. **DO NOT TURN OFF WHILE RECORDING VIDEO.** Stop the recording and allow the video to be saved before shutting off power..

6. Auto-power off function

The camera will save the current file and turn off automatically under the following conditions:

- a. When you shoot video without enough battery power the file will be saved automatically and then auto-power off.
- b. When the disk space of the camera is not enough the recording indicator light will go off and your file will be saved automatically and then auto-power off.
- c. While in standby mode (green light only) if no activity is detected in 60 seconds your camera will automatically power off.

7. Connecting to your computer to retrieve your Videos or Photo Images.

Your camera will function as an external hard drive in order to retrieve the videos and images or for any other purpose. You may connect the camera to your computer while it is powered off, in standby mode or in video mode by using the supplied USB cable. Your computer will recognize it as an external drive and it should appear in your system as a hard drive. At this point you can copy, cut and paste, edit or delete the files located on the SD card. to anywhere on your computer for viewing. Alternately you may also simply remove the SD card from the camera and connect to computer via an SD card reader.

Notice:

- a. If your computer does not recognize your camera within 30 seconds, please unplug the USB cable and insert it again.
- b. For best playback results always play your videos after copying them to your local hard drive.
- c. **Thumb Drive operation:** You can secretly store ANY computer files and move them from computer to computer by storing any data you want onto SD card and removing it on the receiving computer.

8 Web/PC Camera

Before using your camera as web cam you must first install the supplied Windows driver located on the SD card or online at <http://tmenet.com/support/downloads>. The driver name is called SPCA1528_V2220_Multilan_090217.exe . To install, simply double click the file and follow the prompts. After installing there will be a small program called AMCAP. You may use this program to test your camera. or you can use Skype, MSN, Yahoo Messenger, AIM or any other webcam program to test.

Enabling your Web Cam

When you plug in your camera into your USB port on your computer the default mode is to appear as an external drive to your computer. Momentarily press the “Record/Stop ” button to enter the web cam mode and enjoy using your camera for video conferencing and security surveillance applications. Once this mode is established you can switch it back and forth to a web cam by momentarily pressing the “Record/Stop ” button.

9. Reset

If for some reason your device stops responding you may reset the microprocessor by momentarily moving the “ON/OFF” button to “OFF” position and then back to “ON”.

10. Notice

LEGAL Use this camera responsibly and follow all applicable laws in your area.

MOISTURE AND HUMIDITY: Like all electronic devices do not subject a cold unit into a warm humid environment or condensation may form and damage electronics. Do not subject to rain or submerge in water without adequate shielding.

DO NOT EXPOSE TO EXTREME HEAT: This device uses sensitive electronics components. Do not leave exposed to the sun in a hot automobile.

DO NOT AIM AT THE SUN: The sun can produce intense heat at the focal point of the lens and damage the sensor in your camera. Use caution when working outdoors.

CAUTION LITHIUM BATERIES: Do not expose to extreme heat or fire. Please dispose of properly at approved battery collection centers.

Product Made in Hong Kong

